

Engine 616 617

Check that all fasteners on intake manifold, boost air pipe, and exhaust manifold are tightened securely, and retighten, if necessary.

On vehicles with turbocharger, remove air filter for access.

